

1



Sa web stranice www.superior-electronics.com preuzmite i instalirajte besplatan program. Postavite na stol oba, USB programer i Superior Daljinski upravljač jedan nasuprot drugom. LED USB programera trebao bi biti poravnat s tipkom "MUTE" na daljinskom upravljaču, udaljenost 1,5 cm.



2



Provjerite jesu li USB programer i Superior daljinski upravljač u istoj razini.

brzi savjeti



Nikad ne upotrebljavajte USB-Hub za povezivanje USB programera na računalo.



Uvijek izravno spajajte USB programer na USB port vašeg računala.